

COSYSPA HOT TUB BROMINE GRANULES

INSTRUCTIONS

1. Maintain the pH balance between 7.4 - 7,6.
2. On START UP and COMISSIONING of new water, use this product to Shock Dose the water to a minimum of 20 PPM with circulation/ blowers on and all covers off.
3. Test the water with a BROMINE test kit, the ideal reading for Total Bromine is 4 - 6ppm.
4. To increase the Total Bromine reading of the Spa or Hot Tub water by 1ppm add 3g of Spa Brominate Granules per 1000lts of water.
5. Spa Brominate Granules can be added directly to the water with circulation running and water temperature above 20° C.
6. If using this product to "Shock Dose" the water, please wait a minimum of 40 minutes before bathing re-starts.

PRECAUTIONS

- Always ensure bathers are out of the water when adding chemicals.
- Never mix with any other chemicals including cleaning products, weed killers and chorine products, as a dangerous reaction may occur.
- Always handle products in a well-ventilated area.
- Always wash hands thoroughly after handling chemicals.
- Store in a cool, dry well ventilated, secure place. Ensure chemicals do not become damp in storage.
- Instructions and dosages given are a guide to the most effective use.

WARNINGS

- This container must not be used or contaminated with any other materials.