

For optimal bounce & performance, please follow the 5 points below. If using the FORTRESS cricket matting on surfaces other than grass (wooden sprung floors, 3G, 4G, sand, concrete, asphalt etc), start the installation process at step 3.



### **IDENTIFY**

Select a firm & flat area on your grass field that can cater for the mat size you have selected.



### **PREPARE**

Once you have an identified an area, cut the grass short in the targeted space. We recommend grass should be cut to 10-15mm for optimal ball bounce & performance. Any divots must be filled in to ensure under surface is 100% flat. Rolling is recommended.



### **POSITION**

Place your rolled up FORTRESS Instant Mat into the centre of your targeted area & remove any straps or packaging that you no longer need.



### **ROLL OUT**

Ensure mat roll is positioned exactly where you want it & once satisfied with positioning, roll out until completely flat on the ground.



### **WAIT 30 - 45 MINS**

Your FORTRESS Instant Cricket Pitch needs time to settle before use, so we recommend rolling out your mat 30-45 minutes before intended use. Failure to do so may lead to uneven bounce.